Flow limiter not required

Alpha direct Balance base station · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-balance-base-station/flow-limiter-not-required/

Are flow limiters still required when used in conjunction with the OEM Alpha direct Balance System?

Flow limiters are not required when using the OEM Alpha direct Balance System. We recommend keeping the current setting as it is, or setting all flow limiters to full flow.

You can find detailed information on automated hydraulic balancing and government funding schemes in the chapter Automatisierter hydraulischer Abgleich