Switching between heating and cooling

Alpha direct Balance base station · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-balance-base-station/switching-between-heating-and-cooling/

What happens exactly at the base station and thermostat when there’s a switch from heating to cooling?

The base station has a CO input. If this is activated, the base station inverts the signals from the thermostats and transmits them to the valve actuators. An LED indicates that cooling mode is active.