RMO (operating mode)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/selection-of-the-operating-mode-rmo/



MAN

Manual

AUT

Automatic (default)

VAC

Vacation

In “Automatic” mode, the following day-specific **heating**program is saved as standard:

MO – FR	06:00 – 08:00	21 °C
	08:00 – 15:00	19 °C
	15:00 – 22:00	21 °C
	22:00 – 06:00	19 °C
SA – SO	06:00 – 08:00	19°C
	08:00 – 22:00	21°C
	22:00 – 06:00	19 °C

There are 6 switching points available per day.

With “Manual” mode, all programs available under “Automatic” are temporarily suspended until the parameters are reset to “Automatic”. (see → PRG)

With the “Vacation” mode, all programs available under “Automatic” are also deactivated until the parameters are set to “Automatic” again. (see → VAT)