WEH (type of heating)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/weh/



When changing the heating type, it is always essential to check the sensor mode (SMO) and adjust it if necessary.

WH (water-based)

- -Maximum of 10 thermo-electrical actuators can be controlled

EH (electric radiant heating)

- Short-term control of electrical consumers with a maximum of 16A (≤ 3.680 W) possible
- Continuous load without external room sensor (only internal temperature sensor): 5 A (≤ 1.380 W) (see SMO)
- Continuous load only with external room sensor (without internal temperature sensor) : 12 A (≤ 2.760 W)