Cancel pairing

Alpha RF light base station · https://faqdoc.info/en/systemauswahl/alpha-rf-light/alpha-rf-light-base-station/cancel-pairing/

Press and hold: ≥ 3 sec, ≤ 10 sec

Press briefly: ≥ 50 msec, ≤ 2 sec

To cancel the pairing between a heating zone and an Alpha RF light room-control device, proceed as described below:

1. Select the desired heating zone on the Alpha RF light base station
   Press and hold the pairing button (1), see Teaching devices / pairing for at least 3 sec.
   → The heating zone 1 LED flashes quickly.
   → The LEDs of all other heating zones are off.
   Note: To select a different heating zone, briefly press the pairing button (1) again. The LED of the selected heating zone flashes quickly, the LEDs of all other heating zones are off.
   To select a specific heating zone, repeat the procedure until the desired heating zone is reached..
2. **Cancel pairing**
   Press and hold the pairing button (1) again for at least 3 sec. → If the pairing is successfully cancelled, the LED for the selected heating zone stops flashing for 5 seconds.
   After this time has elapsed, the Alpha RF light base station automatically switches to normal operation.
3. **Cancel pairing of further heating zones**
   Repeat steps 1. and 2.

If the procedure is not carried out correctly, the Alpha RF light base station returns to normal operation.