Teaching devices / pairing

Alpha RF light room-control device · https://faqdoc.info/en/systemauswahl/alpha-rf-light/alpha-rf-light-room-control-device/teaching-devices-pairing/

To be able to use the device to control a heating zone, it must first be paired with the **Alpha RF light base station**. For information on this process, see Teaching devices / pairing.

Note: Keep a minimum distance of 50 cm between the devices for pairing.