Error codes

Motoric Valve Drive 24 V (AM3) · https://faqdoc.info/en/systemauswahl/motoric-valve-drive-6/motoric-valve-drive-24-v-am3-en/error-codes/

Errors are indicated by an error code. The subsequent table explains the different error codes and error corrections.

Error code	Description	Error correction
E7	Blockage during initializa-tion run at non-permitted position	1. Disconnect actuator from voltage supply 2. Move the actuator shaft with the manual adjuster out of the end position 3. Re-initialization after switching on the voltage supply again In case of repeated occurrence of the fault, the customer service must be consulted.
E8	Motor current too low	1. Re-initialization by switching the actuator off and on again If the fault cannot be rectified automatically after a maximum of three attempts, contact the customer service.
E9	Driving too long in one direction	1. Re-initialization by switching the actuator off and on again If the fault cannot be rectified automatically after a maximum of three attempts, contact the customer service.