Disassembly

Alpha direct Balance base station · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-balance-base-station/dismantling-2/



Warning! Electrical voltage! Danger to life!

Before opening, de-energize the base and secure it against being re-energized.

Disconnect any external voltages connected to the unit and secure it against accidental re-energization.

1. De-energize the complete installation.
2. Remove the wiring to all externally connected components.
3. Remove the base and dispose it properly, if necessary.