LED signaling

Alpha direct Balance base station · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-balance-base-station/led-signaling-2/

Feature	Color	Explanation
Boiler	Green	**On**: Boiler demand active **Off:** Boiler demand inactive
Pump	Green	**On**: pump demand active **Off**: pump demand inactive **Flashing**: Temperature limiter/dew point monitor active
Mains voltage	Green	**On:** Device in operation **Off**: Device out of service **Flashing:** Commissioning mode active
Fuse	Red	**On:** Fuse defective
Change over	Blue	**On:** Cooling mode active **Off:** Heating mode active
Heating zones (HZ)	Green	**On:** HZ active **Off:** HZ inactive **Flashing:** HZ active; No load balancing