Intended use

Alpha direct Balance Switch base station · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-balance-switch-base-station-en/intended-use/

The base station serves...

- for the arrangement of a room-by-room temperature control system with up to 8 rooms for heating and cooling systems with integrated load balancing function for TÜV-certified automatic hydraulic balancing,
- ... the connection of up to 12 actuators with NC (Normally closed) direction of action.
- ... the connection of up to 8 heating controllers with pulse width modulation (cooling mode via base station).
- .... the connection of a pump, a boiler, a CO signal transmitter, a temperature limiter or dew point sensor, an external timer, for a fixed installation.

Every other use, modification and conversion is expressively forbidden and leads to dangers the manufacturer cannot be held liable for.