ALO / AHI (setpoint limiter)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/alo-ahi/



Setting the maximum and minimum setpoint limiter when using the internal temperature sensor (A). Setting range between 5 °C and 30 °C (41 °F and 86 °F). This limits the setpoint temperature input.

Prerequisite for use:

- Internal sensor A or AF set in sensor mode (→ SMO)

ALO: Setpoint limiter for lowest temperature

AHI: Setpoint limiter for maximum temperature