BRW / BRS (Display brightness)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/brw-brs/



BRW: Display brightness during operation

Setting range 10 ... 100 %, default 20 %

BRS: Display brightness when the device is not in use

Einstellbereich 10 ... 100 %, Standard 20 %

HINWEIS

The maximum brightness of the display when the device is not in use (BRS) corresponds to only 10% of the brightness of the display during operation.