ADP (Smart Start)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/dif-adp/



Prerequisite for use

- Operating mode RMO: AUT
- Control algorithm CMO: HYS

Activation or deactivation of the Smart Start function. This function uses a learning process over several days to adjust the target temperature before the next switching time so that the set target temperature is already reached by the next switching time.