ELO / EHI (setpoint limiter)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/elo-ehi/



Setting the maximum and minimum setpoint limit when using the external room sensor. Setting range between 5 °C and 30 °C (41 °F and 86 °F). This limits the setpoint temperature input.

Prerequisite for use:

- External room sensor A2 or A2F set to sensor mode (→ SMO)

ELO: Setpoint limiter for lowest temperature

EHI: Setpoint limiter for maximum temperature