FLO / FHI (setpoint limiter)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/flo-fhi/



Setting the maximum and minimum setpoint limit for the floor sensor. Setting range between 5 °C and 30 °C (41 °F and 86 °F). This limits the setpoint temperature input.

Prerequisite for use:

- Floor sensor F set in sensor mode (→ SMO)

FLO: Setpoint limiter for lowest temperature

FHI: Setpoint limiter for maximum temperature