Setting up heating programs

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/setting-up-heating-programs/

Define switching times for various heating programmes in the PRG menu

1.

Opening the menu.

Press and hold the system key for 5 sec.:

⭘

2.

Navigate to the menu item **PRG** using the button

🔼 / 🔽

3.

Confirm the selection using the system button

⭘

4.

Depending on the desired switching time: Navigate to one of the menu items **WEE** / **WDA** / **WEN** / **DAY** using the button

🔼 / 🔽

5.

Confirm the selection using the system button

⭘

6.

Set the desired time and temperature using the button:



7.

Confirm the selection using the system button



The number of active LEDs in the top line indicates the switching time (1 – 6).

Add switching time: via **+**

Delete last switching time: via **–**

Exit programming: via **ESC**