SWT (summer time / winter time)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/swt-off/



Automatic switching can be enabled/disabled.

NOTE

The prerequisite for the automatic switching from summer time to winter time is the app and an active cloud connection.