WMO (manual heating / cooling)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/tss-wmo/



Manual selection between heating and cooling. Ideal for standalone solutions without an external CO signal.
Because the controller does not have a CO output, the manual switching function cannot be extended to other controllers, base modules, or systems.

Prerequisite for use:

- Selection of the heating type WEH: WH

HEA: Heating (default)

COO: Cooling