VAL (operating principle)

Alpha direct thermostat 55 Matrix · https://faqdoc.info/en/systemauswahl/alpha-direct-en/alpha-direct-thermostat-55-matrix/val-operating-principle/



Selection of the operating principle of the valve drive used

NC

normally closed (default)

NO

normally open