Auto / Manu mode

Alpha Smart system radiant heating system · https://faqdoc.info/en/systemauswahl/alpha-smartware-en/alpha-smart-system-radiant-heating-system-en/auto-manu-mode/

What does the auto/manual mode mean?

In the app, you can toggle between automatic and manual mode. In automatic mode, the room is heated based on the setpoint temperatures saved in the heating times. By contrast, in manual mode, the setpoint temperature is constant.