Connection set

Alpha Smart system radiant heating system · https://faqdoc.info/en/systemauswahl/alpha-smartware-en/alpha-smart-system-radiant-heating-system-en/connection-set/

The room control device can be equipped with an external sensor input using the connection set. The sensor input has the following functions:

- Room sensor
- Floor sensor
  - Minimum floor temperature monitoring
  - Maximum floor temperature monitoring
- dew point sensor

The connection set can only be used on a room-control device that is paired with a Premium base station!