App

Via NFC

(Near Field Communication)

iOS 14.0/Android 5.0

Preconditions for the use of NFC:

- Knowledge of the existence and position of the NFC interface in the mobile device: The position of the NFC interface varies depending on the model.
- Activated function **NFC,** deactivated display lock

Remove protective covers before using NFC. Ensure a stable support in order to avoid disconnections. The distance required to establish an NFC connection depends on the mobile device used.

Some functions require re-initialization of the OEM Motoric Valve Drive 6: 24 V proportional failsafe. The app is self-explanatory. It is recommended that you follow the instructions in the app.